

GEBRAUCHSANLEITUNG  
USER'S MANUAL

Deutsch  
English

VERSTELLBARE  
KURBELN  
ADJUSTABLE CRANKS

Verstellbare\_Kurbeln\_  
DE-EN

11-20

**REF** Artikel /  
Article  
26770 / 26776 / 26775  
26774 / 26769 / 26705



## FLEX KURBEL

Die Kurbeln können ohne Werkzeug stufenweise um je 15 mm in einem Verstellbereich von 65 – 165 mm verstellt werden.

### KURBELN VERSTELLEN

1. Öffnen Sie den Schnellspanner **(01)**
2. Halten Sie den roten Knopf **(02)** gedrückt und stellen Sie die Kurbel **(03)** auf die gewünschte Länge ein. Lassen Sie den roten Knopf **(02)** los.

**i** HINWEIS! Der rote Knopf **(02)** rastet nur an der Markierung **(04)** ein und muss eingerastet sein.

3. Ziehen Sie den Schnellspanner **(01)** wieder fest.

## ADJUSTABLE CRANK ARMS

The crank arms can be adjusted in 15 mm increments within an adjustment range of 65 – 165 mm (no tools required).

### ADJUSTING THE CRANK ARMS

1. Release the quick-release fastener **(01)**.
2. Press down on the red button **(02)** while adjusting the crank arm **(03)** to the desired length. Release the red button **(02)**.

**i** NOTE! The red button **(02)** only engages at the locations of the markings **(04)** and must lock into place.

3. Close the quick-release fastener **(01)**.

